

# Assembly Instruction



4100021 CABINET JOVE

## STEP 1



## STEP 2



## STEP 3



A: 1PC



B: 4PCS



C: 12PCS



D: 12PCS



E: 1PC